


FIG. 2



T00050" 68299360

FIG. 3




FIG. 4A




FIG. 4B




FIG. 4C




FIG. 4D




FIG. 4E







FIG. 5**FIG. 6**

FIG. 7



T0050" 68799860


FIG. 8

FIG. 9




FIG. 10




FIG. 11




FIG. 13

Figure 1 is a schematic diagram of a control panel for a copier. The panel includes a top status bar with the text "READY TO COPYING (SETTING EXISTING)" and "SETTING CONFIRMATION". A central display area shows the number "0006:" and a prompt "PRINTING IN THIS SETTING ? (SELECT SETTING CHANGE) (KEY IF RESETING)". Below the display are three buttons: "SETTING CHANGE" (labeled 601), "STOP" (labeled 602), and "PRINTING START" (labeled 603). The right side of the panel features a large number "3", a "G" button, a "D" button, a "PAPER" button, and a "SYSTEM SITUATION / STOP" button at the bottom.

FIG. 14




FIG. 15

